

VintageFilm

in combination with **WoW7.2/7.5**



1. Set your HeatPress to 120 - 140°C and medium to high pressure.

2. Press your WoW7.x Transfer onto the garment for 5 Seconds. Let cool down and remove paper liner.

3. Leave the garment on the HeatPress. Take one sheet of VintageFilm and remove the paper liner. Place the Film with the adhesive side down on the WoW Transfer on the garment.

4. Press for 1 Second i.e. close the Press and open right after.

5. Let the garment cool down and strip off the Film.

6. Cover the Transfer with T.Seal (NRP) and press again for 20 Seconds.

Done!

