


OBM 5.4

without T.Pad at lower Temperature



Trim the OBM Transfer to final shape and size. Strip opaque Film carrying the Image of the backing paper. (Hint: Lay Transfer face down on the table and strip paper off the Film.) Position Transfer Film face up on the product and cover with Release Paper.

Note: 'Rule of Thumb' for pressing duration - the higher the temperature the shorter the time!



Take the product off the heatpress and strip Release Paper cool.

Note: Release Paper can be used at least 10 times from both sides.

Note: First wash after minimum 24 hours only!


PRINT



OBM 5.4



PRESS



STRIP

